



- Slide the parallel guide along the fence until it meets the tile, keeping sure that the mark on your tile remains in line with the blade.
- Tighten the locking knob on the parallel guide
- When you are satisfied that the tile is aligned with the blade, and the guide is in place, and it is safe to do so, turn on the power switch and cut
- Check to be sure that the tile has been cut to proper dimensions before using the parallel guide to cut your other tiles. From time to time test the fit of each tile as you continue cutting, to be sure the parallel guide has not moved.

Using the Angle Guide:

Use the angle guide for cutting angled edges on your tiles.

- Attach the angle guide to the fence as you did the parallel guide, using the two locking knobs to hold the guide in place.
- Use the cutting groove in the middle of the table to brace the edge of your tile as you slide the tile and the table underneath the blade.

Diamond Products, Tel: (011) 552 8310, Fax: (011) 552 8312, Email: info@diamondpc.co.za, Web: www.diamondpc.co.za

